

# Heritage Direct Application Spaceloft Aerogel



## APPLICATION

**DO NOT USE ON DAMP WALLS.**

1. Ensure all surfaces are clean and dry and free from any loose material
2. Using a toothed trowel, First Test the adhesive on a small area to check the attachment. If it is good then apply a 2-3mm even coating of Aerogel fixing adhesive.



3. Bed the Aerogel fleece tile into the adhesive. Ensure no gaps are left between the tiles.
4. When dry it is ready for plastering.



## ADDITIONAL FIXING OPTIONS

1. Small areas may not require mechanical fixings; however larger areas can be installed in accordance with the task by either:
  - a) using insulation washers on the joints, or:
  - b) Using insulation washers spaced at 600 centres with AR fibreglass mesh as supplied.



*Aerogel Fix Adhesive has been independently tested as: Non-combustible in accordance with: CAN/ULC S114-5 (Relative Standard: BS EN 13501-1:2007) and Class 1 vapour open in accordance with EN ISO 7783. Patent Pending. Nov 2015.*

## ADDRESS

16 Milltown Industrial Estate  
Upper Dromore Road  
Warrenpoint  
Co Down  
BT34 3PN

## TELEPHONE

+44 (0)28 4177 3314

## EMAIL

info@enviroformsolutions.com

